



*heating and plumbing products
that won't cost the **earth***

BS3 Solar controller

July 2010



BS3 solar controller

Description


The BS3 solar controller is a temperature differential programmer which is supplied as an integral part of and works in conjunction with the FloCal B pump station (code EV29-000683).

It records the temperature at key points in the system and automatically switches on the pump (or pumps) to transfer solar gain heat into a store.

The controller maintains the safety of the system with preset and adjustable limits and allows the installer to provide additional heat sources for back up when no solar heat gains are available.

If required, the controller can be removed from its housing in the pump station and positioned remotely in a different location. Re-connection would be made by extending the wiring and using a suitable electrical junction box.

Operation light
Green for OK
Red for fault



The controller is operated by three pushbuttons.

Button 1 scrolls forward through the options.

Button 2 scrolls back.

Button 3 is the SET command, for when you want to make a change to any of the factory-set values.



**Flo Cal B combined
pump station and controller**



**BS3 solar
controller**